

Position of the safety lifting hook

	Fixed arm						Extendible arm								
Position	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1076423 – capacity: 2500 kg															
Capacity (kg)	2500	2500	2500	1800	1400	1200	1050	950	850	770	700	650	600	560	500
Load centre (mm)	700	950	1200	1450	1700	1950	2100	2300	2500	2700	2900	3100	3300	3500	3700
1076424 – capacity: 5000 kg															
Capacity (kg)	5000	3550	2750	2250	1950	1700	1550	1400	1300	1200	1150	1050	1000	950	900
Load centre (mm)	700	950	1200	1450	1700	1950	2100	2300	2500	2700	2900	3100	3300	3500	3700

Deze hijsarm gebruiken op een heftruck met een capaciteit van maximaal 2.5 ton

Capaciteit hijsarm = 2.5 ton

